

Expansion Arbors

	<p>Mini Expansion Arbor</p> <p>225350 1/2-13 Threads 225360 5/8-11 Threads 225350MM M-16 Threads</p>	<p>Mini Sanding Sleeves</p> <p>P50 Mini 50 Grit P100 Mini 100 Grit P180 Mini 180 Grit</p>
	<p>Small Expansion Arbor</p> <p>225352 1/2-13 Threads 225362 5/8-11 Threads 225352MM M-16 Threads</p>	<p>Small Sanding Sleeves</p> <p>D24 Small 24 Grit D80 Small 80 Grit D120 Small 120 Grit</p>
	<p>Medium Expansion Arbor</p> <p>225354 1/2-13 Threads 225364 5/8-11 Threads 225354MM M-16 Threads</p>	<p>Medium Sanding Sleeves</p> <p>C24 Medium 24 Grit C80 Medium 80 Grit C120 Medium 120 Grit C180 Medium 180 Grit C240 Medium 240 Grit C320 Medium 320 Grit</p>
	<p>Expansion Arbor Kits</p> <p>225380 1/2-13 Threads 225385 5/8-11 Threads 225380MM M-16 Threads</p>	

Maintenance

- The arbor should be cleaned/wiped off with alcohol from time to time to keep the surface of the arbor tacky
- Visually inspect the arbor from time to time to make sure that it has not been damaged

Warranty

This product has a 6 month warranty against manufacturing defects.

At no time should the expansion arbor be used without the proper sanding sleeve listed above. Doing so could cause the arbor to fail and will void the warranty.

Fillauer[®]

2710 Amnicola Hwy
 Chattanooga, TN 37406
 800.251.6398
 423.624.0946
www.fillauer.com